

# Automatic Changeover Unit ECO8020 Datasheet

The ECO8020 is a highly versatile automatic sync and signal changeover unit with configurations and capabilities required to address modern master sync application and other advanced sync timing application. This changeover unit offers exceptional reliability, stability and high availability and is designed with optional high bandwidth input changeover capabilities for HD/SD and/or 3G-SDI signal environments.

#### **Features & Benefits**

Tektronix

- Switches analog black burst, HD tri-level sync, AES/DARS, word clock, LTC, as well as SD/HD/3G-SDI signals - all the timing and synchronization signals required in modern broadcast, production, and post production facilities
- Scalable product architecture to fit various application needs
- Electronic Fast Switch function for near glitch-less sync source switching, minimizing disruption in operations
- Automatic or Manual changeover mode
- Front panel LED fault indicators for each individual channel as well as the status of the power supplies
- Dual hot-swappable power supplies ensure continuous availability of reference signals
- Easy to manage with Web-based interface for configuration and SNMP for status and alert information

#### Applications

- Sync generator and time reference generator system for broadcast, studio, mobile, and post-production facilities
- Master or slave (genlock) operation for distributed system architectures

This changeover unit can be used with the following signal generators to form the complete sync generator system, which offers extra redundancy for the critical timing and synchronization system in the facilities.

- A pair of Tektronix Master Sync / Master Clock Reference Generators (SPG8000) for most broadcast facility timing applications
- A pair of Tektronix Test Signal Generators (TG8000) for more advanced post production facility timing applications

### Instrument configuration


The ECO8020 provides up to 20 user-configurable channels with high density BNC connectors and four LTC channels through the breakout cable. Each channel consists of primary and backup inputs, and an output.

The base configuration has five 50 MHz Electronic Fast Switch channels with options for 15 more 50 MHz Electronic Fast Switch or 3 GHz Relay Switch channels in groups of five channels each, plus four optional LTC channels.

The 50 MHz Electronic Fast Switch channels support black burst, HD trilevel sync, AES/DARS, and word clock signals. The 3 GHz Relay Switch channels support SD/HD/3G-SDI signals as well as most analog reference signals.

For applications that require more than 20 high density BNC channels, two ECO8020 instruments can be configured to work as a single system which practically doubles the number of channels available (up to 40 high density BNC channels and eight LTC channels).





ECO8020 Automatic Changeover Unit front panel and back panel

## **Channel configuration**

Channel configuration can be set either via the front panel or the ECO8020 Web User Interface. Signal amplitude fault detection level follows the setting of the channel configuration. Detection on individual channel may be disabled, giving the option of disabling switching to the backup unit on failure of signals not critical to the facility operation.

## **Changeover switching**

When operated in the switch-on-fault mode, the ECO8020 will automatically select the backup sync source should any of the primary inputs fail. However, in the unlikely event both sync sources are faulty, the ECO8020 will not alternate between the two sources. If necessary, this function may be overridden with the manual sync source selection. Manual source selection also facilitates periodic testing of the changeover function.

#### 50 MHz Electronic Fast Switch channels

The Electronic Fast Switch function, which comes standard with all 50 MHz Electronic Fast Switch channels, significantly improves the changeover switching speed and thus minimizes disturbance of the reference sync signals when switching between primary and backup inputs. The Electronic Fast Switch channels have latching relay backups that engage on loss of power to maintain the selected signal path.

#### **Optional 3 GHz Relay Switch channels**

The optional 3 GHz Relay Switch channels are optimized for SD/HD/3G-SDI signals, but are also usable for most reference signals. These channels utilize high bandwidth latching relays to preserve the selected signal path upon a loss of power.

In addition, these channels are equipped with the Tektronix patent-pending "Relay Check" function <sup>1</sup>. When this function is enabled, the instrument automatically checks the signal level on each 3 GHz Relay Switch channel before and after every changeover switch to determine the condition of the relay contacts of these channels. If it is determined that the relay contacts may have nonconductive coating (such as oxide) buildup, the instrument will cycle the relay rapidly for 20 times to wear through the layer of nonconductive coating in an attempt to restore the relay connections (relay self-cleaning attempt).

### **Optional LTC channels**

The optional LTC channel connections are pin-compatible with the Tektronix SPG8000 and TG8000<sup>2</sup> generators, so these signals can be connected with standard 15 pin D-SUB cables. The same cable can be used to carry GPI connections, which allow the SPG8000 to trigger a changeover on certain error conditions such as loss of genlock.

## **Front panel controls**

In association with the LCD display, front-panel controls are provided for source selection, operating mode, resetting the fault indicators, and for disabling the front-panel controls. LED fault indicators are also provided for each individual channels as well as the status of the power supplies. When the unit is connected to an Ethernet network, these functions are also available from the ECO8020 Web User Interface using a Web browser on a computer connected to the same network.

## **Optional backup power supply**

The optional hot-swappable, redundant (backup) dual power supply system (Option DPW) virtually removes the risk of sync loss due to power supply unit failure, minimizing disruption in operations. Unique to the ECO8000 and ECO8020, the unit periodically tests the backup power supply to verify its performance. If the test fails, a fault will be indicated on the LED fault indicator as well as an error message for backup power supply replacement - providing extra assurance that the backup power supply will be ready when needed.

Each power supply module has both AC and DC indicator LEDs. These LEDs continue to operate for 10 minutes after the loss of power. This allows quick troubleshooting in the event of supply or AC power failure.

## Alarm and status reporting

Alarm and status information can be reported through SNMP, GPI, email notification, and/or the ECO8020 Web User Interface.

<sup>1</sup> The Relay Check function on the 3 GHz Relay Switch channels operates only on channels that are connected (terminated).

<sup>&</sup>lt;sup>2</sup> The TG8000 generator must have a GPS7 module installed in order to support LTC generation.

# Specifications

## Inputs and outputs

Typical return loss		
Base and Option REF 50 MHz Electronic Fast Switch	35 dB, 300 kHz to 6 MHz	
channels	25 dB, 6 MHz to 30 MHz	
Option HREF 3 GHz Relay	40 dB, 300 kHz to 6 MHz	
Switch channels	30 dB, 6 MHz to 30 MHz	
	15 dB, 30 MHz to 1.5 GHz	
	10 dB, 1.5 GHz to 3 GHz	
Insertion loss		
Base and Option REF 50 MHz	< ±0.2 dB DC to 10 MHz	
Electronic Fast Switch channels	Typical < -1 dB DC to 50 MHz	
Option HREF 3 GHz Relay	< -0.1 dB DC to 10 MHz	
Switch channels	Typical < -3 dB DC to 3 GHz	
	Equivalent to approx 5 m of Belden 1694 cable	
Maximum switched voltage		
Base and Option REF 50 MHz Electronic Fast Switch channels	-3 V to +5 V	
Option HREF 3 GHz Relay Switch channels	±2.5 V peak, 1.5 V RMS	
Option LTC channels	±5 V	
Maximum switched current (Option HREF only)	100 mA	
Crosstalk	Unselected input to output or channel to channel	
Base and Option REF 50 MHz	< -60 dB, 300 kHz to 6 MHz	
Electronic Fast Switch channels	< -40 dB, 6 MHz to 50 MHz	
Option HREF 3 GHz Relay	< -48 dB, DC to 1.5 GHz	
Switch channels	< -40 dB, 1.5 GHz to 3 GHz	
Relay switch interruption time	Time that it takes for the relays to switch and settle	
(Option HREF only)	Typically 0.5 ms to 2 ms	
Channel switch settling time (Base and Option REF only with identical signals on both inputs)	Time that it takes for the channel to switch and settle	
Bi-level and Tri-level sync	Typically 5 ns glitch, then 125 ns to 90% of final value	
AES and 1 V word clock	Typically 5 ns glitch, then 250 ns to 90% of final value	
5 V word clock	Typically 25 ns glitch, then 500 ns to 90% of final value	

## ECO8020 Automatic Changeover Unit Datasheet

#### Inputs and outputs

reset threshold signal types	
Base and Option REF 50 MHz Electronic Fast Switch channels	NTSC, PAL, Tri-level, AES, 1 V word clock, 5 V word clock, custom
Opt HREF 3 GHz Relay Switch channels	NTSC, PAL, Tri-level, AES, 1 V word clock, SD-SDI, HD-SDI, 3G-SDI, custom

Signal level range to detect fault -2 dB to -4 dB from the nominal level for the selected signal type with preset thresholds

#### LTC channels

LTC threshold presets	0.5 to 5 $V_{\text{p-p}}$ in 0.5 V steps, differential or single ended
LTC load range	600 $\Omega$ to open circuit
Crosstalk	< -60 dB for LTC signals
Switching interruption duration	Typically 1 ms

#### **Power source**

#### Mains ranges

Voltage	100 to 240 VAC
Frequency	50/60 Hz
Power consumption	50 VA maximum

#### Environmental

Temperature				
Opeating	0 °C to +50 °C (+32 °F to +122 °F)			
Nonoperating	-20 °C to +60 °C (-4 °F to +140 °F)			
Altitude				
Operating	To 9842 ft. (3000 m)			
Regulatory				
EMC	Complies with EMC Directive 2004/108/EC			
Safety				
Approved to:	UL61010-1, CAN/CSA-C22.2 No.61010-1.			
Complies with:	EN61010-1, IEC61010-1.			

## **Physical characteristics**

Dimensions		
Height	43.7 mm (1.72 in.)	
Width	483 mm (19.0 in.)	
Depth	557 mm (21.9 in.)	
Weight		
Net	4.5 kg (10.0 lb.)	

## Ordering information

### **Models**

ECO8020

ECO (automatic changeover) base unit

Includes: 5x 50 MHz Electronic Fast Switch channels using high-density BNC connectors (black burst, HD tri-level sync, AES/ DARS, word clock) and a Quick Start User Manual (Tektronix part number 071-3221-xx)

## **Options**

#### Instrument options

2214					
DPW	Add a second hot-swappable redundant (backup) power supply and second power cord				
REF <sup>3</sup>	Add 5x 50 MHz Electronic Fast Switch channels (black burst, HD tri-level sync, AES/DARS, word clock)				
HREF <sup>3</sup>	Add 5x 3 GHz Relay Switch channels (3G-SDI, HD-SDI, SD-SDI, as well as black burst, HD tri-level sync, AES/DARS, word clock)				
LTC	Add 4x LTC channels				
CBL	Add coaxial adapter cables from high-density male BNC connector to standard male BNC connector (a set of 10 cables, 75 Ω, 18 inches long)				
XLR	Adapter cable (6 feet long) from 15-pin D-sub LTC OUT connector on the ECO8020 to 4 XLR male connectors (for LTC outputs) and BNC male connectors (for General Purpose Interface outputs)				
RACK	Rackmount slides and rails kit (1 RU height, standard full depth)				
Possible channel configurations	Ordering configuration	Slot 1 (Ch. 1-5)	Slot 2 (Ch. 6-10)	Slot 3 (Ch. 11-15)	Slot 4 (Ch. 16-20)
	Base	50 MHz ELSW channels	Empty	Empty	Empty
	Opt. REF	50 MHz ELSW channels	50 MHz ELSW channels	Empty	Empty
	Opt. REF, REF	50 MHz ELSW channels	50 MHz ELSW channels	50 MHz ELSW channels	Empty
	Opt. REF, REF, REF	50 MHz ELSW channels			
	Opt. REF, HREF	50 MHz ELSW channels	50 MHz ELSW channels	3 GHz Relay channels	Empty
	Opt. REF, HREF, HREF	50 MHz ELSW channels	50 MHz ELSW channels	3 GHz Relay channels	3 GHz Relay channels
	Opt. REF, REF, HREF	50 MHz ELSW channels	50 MHz ELSW channels	50 MHz ELSW channels	3 GHz Relay channels
	Opt. HREF	50 MHz ELSW channels	3 GHz Relay channels	Empty	Empty
	Opt. HREF, HREF	50 MHz ELSW channels	3 GHz Relay channels	3 GHz Relay channels	Empty
	Opt. HREF, HREF, HREF	50 MHz ELSW channels	3 GHz Relay channels	3 GHz Relay channels	3 GHz Relay channels

<sup>&</sup>lt;sup>3</sup> You can add any combination of Option REF and HREF channel modules, but the total number of additional modules is limited to three. When both REF and HREF modules are ordered, the REF modules are always installed so that they have lower channel numbers than the HREF modules.

## Power plug options<sup>4</sup>

Opt. A0	North America power plug (115 V, 60 Hz)
Opt. A1	Universal Euro power plug (220 V, 50 Hz)
Opt. A2	United Kingdom power plug (240 V, 50 Hz)
Opt. A3	Australia power plug (240 V, 50 Hz)
Opt. A5	Switzerland power plug (220 V, 50 Hz)
Opt. A6	Japan power plug (100 V, 110/120 V, 60 Hz)
Opt. A10	China power plug (50 Hz)
Opt. A11	India power plug (50 Hz) (No locking cable)
Opt. A12	Brazil power plug (60 Hz) (No locking cable)
Opt. A99	No power cord

## Service options

Opt. C3	Calibration Service 3 Years
Opt. C5	Calibration Service 5 Years
Opt. D1	Calibration Data Report
Opt. D3	Calibration Data Report 3 Years (with Opt. C3)
Opt. D5	Calibration Data Report 5 Years (with Opt. C5)
Opt. G3	Complete Care 3 Years (includes loaner, scheduled calibration, and more)
Opt. G5	Complete Care 5 Years (includes loaner, scheduled calibration, and more)
Opt. R3	Repair Service 3 Years (including warranty)
Opt. R5	Repair Service 5 Years (including warranty)

## ECO802UP field upgrade options

DPW	Add a replacement or a second hot-swappable redundant (backup) power supply. A power cord option must be specified. (See <i>Power Cord Options.</i> )
LTC	Add 4x LTC channels (software upgrade option)
CBL	Add coaxial adapter cables from high-density male BNC connector to standard male BNC connector (a set of 10 cables, 75 Ω, 18 inches long)
XLR	Adapter cable (6 feet long) from 15-pin D-sub LTC OUT connector on the ECO8020 to 4 XLR male connectors (for LTC outputs) and BNC male connectors (for General Purpose Interface outputs)
RACK	Rackmount slides and rails kit for ECO8020 (1 RU height, standard full depth)
IF	Upgrade installation service
IFC	Service installation and calibration

<sup>4</sup> All power cords include a locking mechanism except as otherwise noted.



Option XLR adapter cable



Option DPW backup power supply



Option CBL adapter cable



Tektronix is registered to ISO 9001 and ISO 14001 by SRI Quality System Registrar.

ASEAN / Australasia (65) 6356 3900 Belgium 00800 2255 4835\* Central East Europe and the Baltics +41 52 675 3777 Finland +41 52 675 3777 Hong Kong 400 820 5835 Japan 81 (3) 6714 3010 Middle East, Asia, and North Africa +41 52 675 3777 People's Republic of China 400 820 5835 Republic of Korea 001 800 8255 2835 Spain 00800 2255 4835\* Taiwan 886 (2) 2722 9622

Austria 00800 2255 4835\* Brazil +55 (11) 3759 7627 Central Europe & Greece +41 52 675 3777 France 00800 2255 4835\* India 000 800 650 1835 Luxembourg +41 52 675 3777 The Netherlands 00800 2255 4835\* Poland +41 52 675 3777 Russia & CIS +7 (495) 6647564 Sweden 00800 2255 4835\* United Kingdom & Ireland 00800 2255 4835\*

Balkans, Israel, South Africa and other ISE Countries +41 52 675 3777 Canada 1 800 833 9200 Denmark +45 80 88 1401 Germany 00800 2255 4835\* Italy 00800 2255 4835\* Mexico, Central/South America & Caribbean 52 (55) 56 04 50 90 Norway 800 16098 Portugal 80 08 12370 South Africa +41 52 675 3777 Switzerland 00800 2255 4835\* USA 1 800 833 9200

\* European toll-free number. If not accessible, call: +41 52 675 3777

For Further Information. Tektronix maintains a comprehensive, constantly expanding collection of application notes, technical briefs and other resources to help engineers working on the cutting edge of technology. Please visit www.tektronix.com.

Copyright <sup>©</sup> Tektronix, Inc. All rights reserved. Tektronix products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TEKTRONIX and TEK are registered trademarks of Tektronix, Inc. All other trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies. 20W-29404-1 06 May 2014

www.tektronix.com

**Tektronix**<sup>®</sup>

Updated 10 April 2013

123

## testforce

For more information contact us at sales@testforce.com, or call us toll-free at 1(888)880-6804. www.testforce.com